

**HPS-110**

# **HandyPort-Serial**

**Wireless Solutions in your Hand**

***User's Manual***

Version 2.0



**HandyWave**

## Table of Contents

<b>1. INTRODUCTION</b>	<b>3</b>
1.1. FEATURES	3
1.2. PACKAGE	3
<b>2. SPECIFICATIONS</b>	<b>4</b>
2.1. GENERAL	4
2.2. INTERFACE	5
2.2.1. <i>Notation</i>	5
2.2.2. <i>RS-232 Signals</i>	5
2.3. FACTORY SETTINGS	6
2.4. STATUS LED	6
2.5. RESET BUTTON	6
2.5.1. <i>Entering the Configuration Mode</i>	6
2.5.2. <i>Exiting the Configuration Mode</i>	6
2.5.3. <i>Re-connection</i>	6
<b>3. USAGE</b>	<b>7</b>
3.1. HARDWARE INSTALLATION	7
3.2. HYPER TERMINAL SETTINGS	7
3.3. CONFIGURATION	7
3.3.1. <i>Starting Configuration</i>	7
3.3.2. <i>Usage Printing</i>	7
3.3.3. <i>After Configuration</i>	7
3.4. COMMAND SET	8

# 1. Introduction

---

Thank you for purchasing a HandyPort-Serial. The HandyPort-Serial can be used as a component in many types of systems allowing them to communicate wirelessly with other Bluetooth products such as PC-cards, laptops, handheld computers, mobile phones and other HandyPort-Serial. The HandyPort-Serial is a suitable component in new products as well as in existing products.

## 1.1. Features

- Supports Bluetooth Serial Port Profile and Generic Access Profile
- No need of external host and software
- Easy of installation and use
- Supports configuration of the local device
- Supports configuration of the remote device via Over-the-Air
- Easy of maintenance
- Supports up to 100 meter (Line of Sight)

## 1.2. Package

- HPS-110 2 EA
- Antenna 2 EA
- A soft copy of this manual<sup>1</sup>

---

<sup>1</sup> This manual is required the software version 2.0 or above. If you have any questions, please contact us.

HandyWave Co., Ltd.

202-4 yatap-dong, Bundang-gu, Seongnam City, Gyunggi Province 463-070, Republic of Korea

Tel: 82-31-709-8900, Fax: 82-31-708-9455

<http://www.handywave.com/index3.htm>

## 2. Specifications

### 2.1. General



Baud Rate	<ul style="list-style-type: none"><li>● Up to 115.2kbps (Recommend above 2.4kbps)</li><li>● Supports 1.2/2.4/4.8/9.6/19.2/38.4/57.6/115.2kbps</li></ul>
Coverage	Up to 100 M
Connection	Point-to-Point
Signal	TxD, RxD, GND
RS-232 Interface	2.5mm Wire to Board Connector Angle Type 4 Pin Male <sup>1</sup>
Standard	Bluetooth Specification Version 1.1
Frequency	2.400 ~ 2.4835GHz
Hopping	1,600/Sec, 1MHz Channel Space
Modulation	GFSK, 1Mbps, 0.5BT Gaussian
Tx. Power	Max 20 / Typical 16dBm (Class 1)
Rx. Sensitivity	-84dBm
Antenna Interface	SMA Female
Antenna Gain	Max. 2dBi
Power Supply	+3.3 ~ 16VDC
Current Consumption	Max. 110mA
Operation Temperature	-20 ~ 75 °C
Size	36.5mm (W) x 69mm (D) x 12mm (H)

<sup>1</sup> Part number: 22-05-7045 (Old Part Number: 5268-04A) from Molex. Other side part number: 50-37-5043 (Old Part Number: 5264-04) from Molex.

## 2.2. Interface

### 2.2.1. Notation

- PWR: Power LED
- OPR: Link LED
- ANT: Antenna Connector (SMA Female)
- RST: Reset Button
- GND: Signal Ground
- RXD: RS-232 Received Data
- TXD: RS-232 Transmitted Data
- VCC: System Power



### 2.2.2. RS-232 Signals

Pin Number	Notation	Direction	Description
1	VCC	Input	Vcc 3.3V ~ 16V
2	TxD	Output	RS-232 Transmitted Data
3	RxD	Input	RS-232 Received Data
4	GND	N/A	Signal Ground

## 2.3. Factory Settings

The following are the factory settings of COM port. You can change the factory settings of COM port with commands. In this case, you have to remember the changed factory settings.

- Baud rate: 9600 bps
- Data Bit: 8 bit
- Parity Bit: No parity
- Stop Bit: 1 stop bit
- Flow control: None

## 2.4. Status LED

There are two LED on HPS-110.

- PWR (Green): It is an indication of power on/off status.
- LNK (Green): When a wireless link is on, it is turned on. If HPS-110 is in the configuration mode, it will be flashing every second.

## 2.5. Reset Button

The RST button has the following functions.

- Enter / Exit the configuration mode
- Restore the factory settings<sup>1</sup>
- Disconnect and reconnect a wireless connection.

### 2.5.1. Entering the Configuration Mode

When the LNK LED is OFF, push the RST button. When the LNK LED is ON, you have to push the RST button twice to enter the configuration mode. If you enter the configuration mode successfully, LNK LED will be flashing every second. And HPS-110 COM port will be stored the factory settings.

### 2.5.2. Exiting the Configuration Mode

You can have two options to exit the configuration mode.

- Exit the configuration mode by software: Type "X".
- Exit the configuration mode by the RST button: Push the RST button.

### 2.5.3. Re-connection

When the LNK LED is on, you can push the RST button to disconnect and reconnect a wireless link.

---

<sup>1</sup> If you push the RST button, the COM port of HPS-110 will be stored the factory settings.

## 3. Usage

---

You can change the configuration of HPS-110 using Hyper Terminal<sup>1</sup>.

### 3.1. Hardware Installation

Step 1: Assemble a provided antenna to HPS-110 body.

Step 2: Plug a HPS-110 into the COM port of device.

Step 3: Power on.

Step 4: Configure the HPS-110, if necessary.

### 3.2. Hyper Terminal Settings

Baud Rate: 9600 bps / Data Bit: 8 / Parity Bit: None / Stop Bit: 1 / Flow Control: None /  
Emulation: VT100

### 3.3. Configuration

#### 3.3.1. Starting Configuration

Step 1: Plug a HPS-110 into a COM port of PC. And Power it on.

Step 2: Open a Hyper Terminal and set it up.

Step 3: Push the RST button on HPS-110. If you enter the configuration mode successfully, LNK LED will be flashing every second.

Step 4: Hit the <Enter> key, 5 second later.

Step 5: Change the configuration of HPS-110 with commands, if necessary.

#### 3.3.2. Usage Printing

If you are in the configuration mode, type “?<Enter>” for listing of commands. If you want to know the usage of a command, type “?[command]<Enter>”. All commands and parameters are case sensitive. And you cannot use a <Backspace>.

#### 3.3.3. After Configuration

After finishing the configuration, you have to execute a command “X” to apply changes.

---

<sup>1</sup> This manual is required the software version 2.0 or above.

### 3.4. Command Set

The commands are as follows<sup>1</sup>:

Item	Syntax	Description	Remarks
1. Connecting address	<b>A</b> <u>Addr</u> <CR>	Set a remote device address for a wireless connection.	A local and remote BD_ADDR always need to be difference.
2. Baud rate	<b>B</b> <u>BR</u> [ <b>D</b> ]<CR>	Change the baud rate. D (option): Change a factory setting <sup>2</sup> .	Baud Rate (BR) - 0: 1200, 1: 2400, 2: 4800, 3: 9600, 4: 19200, 5: 38400, 6: 57600, 7: 115200
3. COM port	<b>C</b> <u>COM</u> <b>P</b> ort<CR>	Change a request serial port.	COMPort: '1' ~ '7' Only valid in connection mode 2.
4. PIN code	<b>E</b> <u>PIN</u> <CR>	Authentication Off: hit <Enter> Authentication On: Type up to 11 characters	Paired adapters should have a same PIN code.
5. Search timer	<b>G</b> <u>T</u> O<CR>	Set a search timeout. TO (timeout): ASCII '0' ~ "999"	Connection mode 3 only. Default: 10 sec.
6. Max number of search	<b>H</b> <u>N</u> O<CR>	Set the max number of search. NO: ASCII '0' ~ "999"	Connection mode 3 only. Default: 10
7. Search device	<b>I</b> <u>T</u> O, <b>N</b> O <b>I</b> L<CR>	Execute searching devices. TO: ASCII '0' ~ "999" NO: ASCII '0' ~ "999" L (option): Display a long form.	Connection mode 3 only. ';': ASCII 0x2C
8. Discovery mode	<b>J</b> <u>E</u> / <b>D</b> <CR>	Set the discovery mode. 'E': Enable 'D': Disable	Connection mode 1 only. Default: Enable
9. Low Power Mode	<b>K</b> <u>E</u> / <b>D</b> <CR>	Set the low power mode. 'E': Enable 'D': Disable	Default: Disable

<sup>1</sup> If you push the RST button, the COM port of HPS-110 will be stored the factory settings.

<sup>2</sup> If you change a factory setting for baud rate, you have to remember it.



10. Connection mode	MMode<CR> <sup>1</sup>	Set a connection mode. Mode: '0' – '3' Mode 0 & 2: Required a remote address. Mode 2: Required a serial port.	0: 1:1 Mode 1: WAIT Mode 2: REGISTER and CONNECT Mode 3: WAIT Command Mode
11. Friendly name	NName<CR>	Set a friendly name up to 11 characters.	
12. Parity Bit	PParity <sup>2</sup> <CR>	Set the parity bit. D (option): Change a factory setting <sup>3</sup> .	0: None, 1: Odd 2: Even
13. Connection Timeout	QTO<CR>	Set the connection timeout. TO: ASCII '0' ~ "999"	Connection mode 3 only. Default: 10 sec.
14. Stop Bit	SST[D]<CR>	Set the stop bit. D (option): Change a factory setting <sup>4</sup> .	0: 1 Stop, 1: 2 Stop
15. Connect	TAddr[,TO]<CR>	Try to make a connection. Addr: a remote address TO (option): ASCII '0' ~ "999"	Connection mode 3 only. ,: ASCII 0x2C Default Timeout: 10 sec.
16. Cancel	U	Cancel a command.	Connection mode 3 only.
17. View	V	Display the device information	You can find out a software version.
18. CoD	WCoD<CR>	Set the class of device. CoD: 6-Hex in ASCII	Default: "001F00"
19. Exit	X	Apply changes.	Rebooting
20. Status	Z	Display the status of state machine.	'S': Idle / 'P': Pairing / 'C': Connecting / 'A': RF on / 'I': Inquiring
21. Usage	?[C]<CR>	Display the command list or usage. C: Command	AT+Z?<CR>: Command list AT+Z?A<CR>: Usage of 'A'

<sup>1</sup> <CR>: Carriage Return (0x0D)

<sup>2</sup> []: An optional parameter.

<sup>3</sup> If you change a factory setting for parity bit, you have to remember it.

<sup>4</sup> If you change a factory setting for stop bit, you have to remember it.